


BASIC FUNCTIONS & PHONE SETUP

BUTTONS

All functions are controlled by 3 Buttons. "Power", "Up" and "Down".

Note: "Power" Button is also "Answer" button for incoming calls.



POWER ON



Press & Hold "Power" for 2 seconds.


POWER OFF



Press & Hold "Power" for 5 seconds

CHARGING

Charge AMP Go completely after purchase. Must charge with supplied USB cable. Use the provided charging cable by connecting it either to a USB port or to the AC/DC adaptor provided. While charging, the status indicator light will be red. Upon being fully charged, the status indicator light will be blue.




VOLUME UP



Press & Release "Up" once per level.

SPEAKER PLUG

Insert the speaker's USB wire into the AMP unit until you can no longer see the 3 ribs on the speaker wire plug. The connection will be tight.




NOTICE

REFER TO FULL PDF USER GUIDE FOR INSTALLATION

PAIR TO SMARTPHONE

- 1) Power on the unit. Hold both "Up" and "Down" 2 seconds until LED blinks red and blue.
- 2) Turn on your phone's Bluetooth, search Bluetooth device list, and select/connect your AMP Go.
- 3) After successful pairing, power off AMP Go to store phone into memory. When AMP Go is next powered on, it will auto connect to your phone.



VOLUME DOWN



Press & Release "Down" once per level.

DOWNLOAD CLEARLink APP

CLEARLink is a FREE smartphone app with tools to customize, configure and update your AMP Go settings anytime, anywhere.

ClearLink is available in the Apple App Store and Google Play Store.


CLEARLink
MOBILE APP




For how-to videos and full user manual download and refer to the **CLEARLink App**.

PHONE & MUSIC FUNCTIONS

PHONE FUNCTIONS




ANSWER INCOMING CALL
Say "Hello" or
Press "Power" once



REJECT OR END CALL
Hold "Power"
1 Second



REDIAL LAST NUMBER
Hold "Power" and
"Up" 2 seconds



VOICE DIAL
Hold "Power" and
"Down" 2 seconds


MUSIC PLAYBACK




PLAY / RESUME MUSIC
Press
"Power" twice



STOP/PAUSE MUSIC
Press
"Power" once



BACKTRACK
Press
"Down" twice






FAST FORWARD
Press
"Up" twice

INTERCOM

GROUP INTERCOM PAIRING

- 1) Power off all the units to be paired.
- 2) On the first unit, hold "Power" & "Down". LED will blink purple.
- 3) On the 2nd unit, hold "Power" & "Up" buttons 5 seconds. Wait at least 10 seconds or until previous unit is double-blinking blue or green.
- 4) Repeat step 3 for additional units. Go to step 5 if no more units.
- 5) To end the pairing process, press "Power" on the last unit in the chain. All units should be double blinking blue or green.
- 6) Power off all units to store pairing into memory.




ACTIVATE / DEACTIVATE INTERCOM MODE

To activate intercom mode, power on all paired units and hold the "Up" button on any unit for 2 seconds. You will hear a confirmation beep.



To deactivate intercom mode, press and hold the "Down" button for 2 seconds on any unit in the pairing group.



For how-to videos and full user manual download and refer to the **CLEARLink App**.